

Universal Survivor™ Roll #SVRS150H-1 - 15" x 150', 1 roll/package



The absorbency of a mat and the durability of a rug — hides the grunge to stay on the job longer.

- Camouflage pattern in gray makes leaks and drips disappear
- Five-star durability withstands foot traffic in production areas, near machines and in walkways
- Innovative 3-ply construction combines our toughest SpunBond top layer, highly absorbent core and a bottom layer designed to grip floors
- Perforations allow you to tear rolls into different sizes based on your application
- Rolls are ideal for covering large areas

SVRS150H-1 Specifications

| | |
|-----------------------------|-----------------------------|
| Dimensions: | 15" W x 150' L |
| Shipping Dimensions: | 17" W x 17" L x 15" H |
| Sold as: | 1 roll per package |
| Color: | Camouflage |
| Composition: | Polypropylene |
| Absorbency: | Up to 17.9 gal. per package |
| # per Pallet: | 30 |
| Basis Weight: | HeavyWeight |
| Incinerable: | Yes |
| Ship Class: | 150 |

Metric Equivalent Specifications

| | |
|-----------------------------|--------------------------------|
| Dimensions: | 38.1cm W x 46m L |
| Shipping Dimensions: | 43.2cm W x 43.2cm L x 38.1cm H |
| Absorbency: | Up to 67.8 L per package |

SVRS150H-1 Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com