

Oil-Only Commander™ Roll #WRF150M - 30" x 150', 1 roll/package



Durable FineFiber mat controls oil under machines and conveyors

- Most popular mat used in industrial cleanup applications
- Use near machinery, in production areas and under assembly lines and conveyors
- 3-ply construction is strong and absorbent to take command of leaks and spills and good for foot traffic
- Rolls are ideal for covering large areas
- Perforations allow you to tear rolls into different sizes based on your application
- Oil selective repels water but absorbs oil and all oil-based fluids

WRF150M Specifications

Dimensions: 30" W x 150' L

Shipping 14" W x 30" L x 14" H

Dimensions:

Sold as: 1 roll per package

Color: White

Composition: Polypropylene

Absorbency: Up to 39.5 gal. per package

per Pallet: 2°

Basis Weight: MediumWeight

Incinerable: Yes Ship Class: 150

Metric Equivalent Specifications

Dimensions: 76.2cm W x 46m L

Shipping 35.6cm W x 76.2cm L x 35.6cm H

Dimensions:

Absorbency: Up to 149.5 L per package



Phone: 1-800-228-3877 (N.Am.) 1-770-475-3877 (Other) Fax: 1-800-872-3764 (N.Am.) 1-770-410-1812 (Other) Email: sales@spilltech.com

WRF150M Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:

(Available at **spilltech.com**)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

