

## Oil-Only Transformer™ Roll #WRSMF100H-BX - 15" x 100', 1 roll/package



Versatile All-In-One Mat is a Roll, Pad and Sock. One product is all you need!

- This innovative mat features a SpunBond top layer that wicks liquids away into the MeltBlown core to keep the mat and floors safe and dry. The bottom layer is built of densely woven strands of FineFiber to increase surface area, enabling the mat to grip the floor and securing it for safer walking. All layers are ultrasonically bonded together for durability and resistance to wear in high traffic areas. Strong and long-wearing, this mat stays on the job so you use less and save money
- Perfed 3.75" vertically and 17" horizontally to tailor mat's dimensions to your applications
- Comes in grunge-hiding gray for universal jobs or bright white for oil-only applications
- Packaged in a convenient dispenser box

### WRSMF100H-BX Specifications

<b>Dimensions:</b>	15" W x 100' L
<b>Shipping Dimensions:</b>	16" W x 16" L x 16" H
<b>Sold as:</b>	1 roll per package
<b>Color:</b>	White
<b>Composition:</b>	Polypropylene
<b>Absorbency:</b>	Up to 18.9 gal. per package
<b># per Pallet:</b>	30
<b>Basis Weight:</b>	HeavyWeight
<b>Incinerable:</b>	Yes
<b>Ship Class:</b>	175

### Metric Equivalent Specifications

<b>Dimensions:</b>	38.1cm W x 30m L
<b>Shipping Dimensions:</b>	40.6cm W x 40.6cm L x 40.6cm H
<b>Absorbency:</b>	Up to 71.5 L per package

## WRSMF100H-BX Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

### Technical Documents:

(Available at [spilltech.com](http://spilltech.com))

Product Data Sheet (PDS)

Safety Data Sheet (SDS)



**SpillTech**

Online:  
[spilltech.com](http://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)