

## Oil-Only Cart Kit Refill #RSPKO-CART - Absorbs up to 109.9 Gallons



Refill your SpillTech® Oil-Only Spill Kit Cart to ensure fast response.

## RSPKO-CART Specifications

## Metric Equivalent Specifications

<b>Sold as:</b>	3 per package
<b>Absorbency:</b>	Up to 124.2 gal. per package
<b># per Pallet:</b>	6
<b>Incinerable:</b>	Yes
<b>Ship Class:</b>	175
<b>Includes:</b>	100 - 15" x 19" White Oil-Only HeavyWeight SonicBonded Pads (WPB100H) 4 - 5" x 10' White Oil-Only Sock/Net Booms (WB510SN) 2 - 8" x 20' White Oil-Only Sock/Net Booms (WB820SN) 2 - 6" x 16" x 21" Red Oil-Only Net Pillows (WPIL10) 4 - 8" x 18" White Oil-Only Sorbent Pillows (WPIL818) 1 - Emergency Response Guidebook (A-EGB) 4 - 30" x 6" x 60" Yellow Disposal Bags & Ties (A-DISP BAG) 1 - Pair Nitrile Gloves (A-GLV-NIT) 1 - Safety Goggles (A-GOG) 1 - 3" x 5" Vinyl Spill Kit Label (A-KITLABEL) 6 - 6" X 2" TamperProof Seals (A-SEAL)

<b>Absorbency:</b>	Up to 470.1 L per package
--------------------	---------------------------



**SpillTech**

Online:  
[spilltech.com](http://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)

## RSPKO-CART Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

### Technical Documents:

(Available at [spilltech.com](http://spilltech.com))

Product Data Sheet (PDS)



Online:  
[spilltech.com](http://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)