

Oil-Only Kaddie Kit Refill #RSPKO-KAD - Absorbs up to 27.7 Gallons



Refill your SpillTech® Oil-Only Kaddie Spill Kit to ensure fast response.

RSPKO-KAD Specifications

Dimensions: 16" W x 20" L x 17" H **Shipping** 16" W x 20" L x 17" H

Dimensions:

Sold as: 1 per package

Composition: N/A

Absorbency: Up to 27.7 gal. per package

per Pallet: 30 Incinerable: Yes Ship Class: 150

Includes: 100 - 10" x 14" White Oil-Only

HeavyWeight FineFiber Pads

(WPF1014H)

6 - 3" x 4' White Oil-Only Sorbent

Socks (WSO430)

4 - 8" x 18" White Oil-Only Sorbent

Pillows (WPIL818)

1 - 7" Epoxy Putty Stick (A-EPOXY)

1 - 6" Glow Light Stick (A-

LIGHTSTICKS)

1 - Emergency Response Guidebook

(A-EGB)

5 - 18" X 30" Yellow Disposal Bags &

Ties (A-DISPBAG-SM)

2 - Pair Nitrile Gloves (A-GLV-NIT)

1 - Safety Goggles (A-GOG)

1 - 3" x 5" Vinyl Spill Kit Label (A-

KITLABEL)

Metric Equivalent Specifications

Dimensions: 40.6cm W x 50.8cm L x 43.2cm H **Shipping** 40.6cm W x 50.8cm L x 43.2cm H

Dimensions:

Absorbency: Up to 104.8 L per package



Phone: 1-800-228-3877 (N.Am.) 1-770-475-3877 (Other) Fax: 1-800-872-3764 (N.Am.) 1-770-410-1812 (Other) Email: sales@spilltech.com

RSPKO-KAD Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

