

# Universal 95-Gallon Recycled Spill Kit Refill #RSPKU-95-RC - Absorbs up to 89.9 Gallons



Refill your Universal 95-Gallon Recycled Spill Kit to ensure fast response. Socks, Pillows and our exclusive SpillTech® AirLaid Sorbent Mats are made with 100% recycled filler, ideal for helping maintain a greener workplace.







Email: sales@spilltech.com

## **RSPKU-95-RC Specifications**

## **Metric Equivalent Specifications**

Dimensions:	18" W x 24" L x 22" H	Dimensions:	45.7cm W x 61cm L x 55.9cm H
Sold as:	2 per package	Absorbency:	Up to 340.3 L per package
Composition:	Various	Absorbency.	Op to 340.3 L per package
-			
<b>Recycled Content:</b>	95% Post-Industrial Recycled		
	Polypropylene		
Absorbency:	Up to 89.9 gal. per package		
Incinerable:	Yes		
Includes:	150 - 15" x 19" Gray Universal		
	HeavyWeight AirLaid Pads		
	(GPA100H)		
	12 - 3" x 4' Gray Universal Sorbent		
	Socks (GSO430)		
	6 - 3" x 8' Gray Universal Sorbent		
	Socks (GSO815)		
	7 - 18" x 18" Gray Universal Sorbent		
	Pillows (GPIL1818)		
	3 - 1 lb. Plug & Dike Epoxy Putty (A-		
	PND )		
	2 - Pair Nitrile Gloves (A-GLV-NIT)		
	1 - Safety Goggles (A-GOG)		
	4 - 30" x 6" x 60" Yellow Disposal		
	Bags & Ties (A-DISPBAG)		
	1 - Emergency Response GuideBook		
	(A-EGB)		
	1 - 3" x 5" Vinyl Spill Kit Label (A-		
	KITLABEL)		







Email: sales@spilltech.com

## **RSPKU-95-RC** Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

#### **Regulations and Compliance:**

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

40 CFR 112.7(c)(1) - Facilities must have "appropriate containment and/or diversionary structures to prevent discharge oil from reaching a navigable water course."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

### **Technical Documents:**

(Available at spilltech.com)

Product Data Sheet (PDS) Chemical Compatibility (CCG)







Email: sales@spilltech.com